

B85 audio

# FUZZ MACHINE



- **pregain:** ovládá velikost zisku ve vstupní fázi. Funguje to s potenciometrem CLEAN, takže je důležité pochopit, jak spolupracují. Když je přepínač PHASE nahoru, funguje PREGAIN jako pre-fuzz. Když je přepínač PHASE dolů, PREGAIN stále funguje na fuzzu, ale také ovlivňuje čistý signál.
- **fuzz:** mění množství fuzz a harmonickou strukturu.
- **shape:** mění tvarování filtru. Proti směru hodinových ručiček se ubírá výšky, zatímco ve směru hodinových ručiček přináší zpět vysoký tón a středy.
- **fuzz vol:** ubírá a přidává hlasitost potenciometru fuzz.
- **clean:** při nastavení úplně doleva je jen zvuk fuzz, přidáváním mixujete s čistým signálem.
- **mids přepínač:** když je nahoru, mírně přidáte dolní středové frekvence a když je dolů, mírně přidáte středy v horním rozsahu.
- **phase přepínač:** když je nahoru, má pregain vliv poze na fuzz a když je dolů tak pregain ovlivňuje jak fuzz, tak i čistý signál.

**K napájení používejte pouze kvalitní adaptér 9V DC center negativ.**

Uvnitř se nachází DIP přepínač, který slouží k zapnutí a vypnutí vyrovnávací paměti. Aby byl buffer zapnutý, přepněte 1 dolů a 2 a 3 nahoru. Chcete-li vyrovnávací paměť obejít, přepněte 1 nahoru a 2 a 3 dolů.

B85 audio

# FUZZ MACHINE



- **pregain:** controls the amount of gain in the input phase. It works with the CLEAN potentiometer, so it's important to understand how they work together. When the PHASE switch is up, PREGAIN works as a pre-fuzz. When the PHASE switch is down, PREGAIN still operates on fuzz, but also affects the clear signal.
- **fuzz:** changes the amount of fuzz and harmonic structure.
- **shape:** changes the shape of the filter. Counterclockwise decreases treble, while clockwise brings back high pitch and mids.
- **fuzz vol:** removes and adds volume to the fuzz potentiometer.
- **clean:** when set to the far left, it's just a fuzz sound, adding it mixes with a clear signal.
- **mids switch:** when it is up, you slightly add the lower center frequencies, and when it is down, you slightly add the mids in the upper range.
- **phase switch:** when it is up, pregain only affects fuzz, and when it is down, pregain affects both fuzz and pure signal.

**Use only a high-quality 9V DC center negative adapter for power supply.**

Inside is a DIP switch that turns the buffer on and off. For the buffer to be on, switch 1 down and 2 and 3 up. To bypass the buffer, switch 1 up and 2 and 3 down.